

# Repair Parts


116.427.AB.4T

Touch-free, programmable faucet with above-deck electronics

# CHICAGO FAUCETS®

Geberit Group

## Base Parts:



## For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: [techsupport.us@chicagofaucets.com](mailto:techsupport.us@chicagofaucets.com)

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

[chicagofaucets.com](http://chicagofaucets.com)


# Repair Parts

116.427.AB.4T


Touch-free, programmable faucet with above-deck electronics

**CHICAGO  
FAUCETS®**  
Geberit Group


5-1/4" Rigid/Swing Gooseneck Spout with Flow Control  
**GN2H8FCJKABCP**



Electronic Module  
**242.433.00.1T**



AC Power System  
**AC Power**



ERROR:  
No image found.

## For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: [techsupport.us@chicagofaucets.com](mailto:techsupport.us@chicagofaucets.com)

2100 South Clearwater Drive  
Des Plaines, IL 60018  
Phone: 847-803-5000  
[chicagofaucets.com](http://chicagofaucets.com)