

Repair Parts


116.104.AB.4

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

HyTronic Base for Wall, No Mixer

Base Parts:



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com


Repair Parts

116.104.AB.4


Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group


5-1/4" Rigid / Swing Gooseneck Spout
GN2AH8JKABCP




Electronic Module
242.574.00.1



0.35 GPM (1.3 L/min) Vandal Proof Econo-Flo Non-Aerating
Outlet
E38VPJKABCP



AC Power Adapter
240.747.00.1



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com