


Repair Parts

116.429.AB.1

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

Base Parts:



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com


Repair Parts

116.429.AB.1


Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group


5-1/4" Rigid/Swing Gooseneck Spout with Flow Control
GN2H8FCJKABCP




Electronic Module
242.433.00.1



AC Power Adapter
240.747.00.1



Bank Installation Adapter Wire
242.340.00.1



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com