


Repair Parts

116.659.AB.1T

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

Base Parts:



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

ADAPTER (GREEN)
242.568.00.1

LONG LIFE
BATTERY
243.867.00.1

Diagram illustrating the components of a hose assembly, showing the hose and various fittings and washers.

Components and Part Numbers:

- FLOW CONTROL 1.5 GPM
50-043KJKABNF
- FLOW CONTROL 1.5 GPM
1020-006JKABNF
- O-RING 0.739 x .070
50-035JKABNF
- NUT, SPOUT
1-1/16-18 UNEF
1100-208JKCP
- SPLIT WASHER
50-036JKNF
- CELCON WASHER
340-004JKABNF
- KIT, BAG
WASHERS AND NUT
226-TJKABCP

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com